



EYELETS ARE REQUIRED AT THESE LOCATIONS UNDER EACH RELAY AND THE CONNECTORS, TOTAL 32 EYELETS ENCLOSED

INSTRUCTIONS TO INSTALL EYELETS: INSTALL EYELETS FROM COMPONENT SIDE OF BOARD

SOLDER THE RIM OF THE EYELET ON THE COMPONENT SIDE OF THE BOARD, DO NOT FILL THE EYELET WITH SOLDER
TURN THE BOARD OVER ON A PEICE OF SCRAP WOOD AND WITH A HAMMER AND THE ENCLOSED TOOL, PLACE THE TAPERED END OF THE TOOL IN THE EYELET
TAP THE TOOL AND EXPAND THE EYELET SO THE EYELET IS TIGHT IN THE BOARD

PARTS LIST

- (6) RELAYS : AMERICAN ZETTLER, INC AZ755-1C-12DE
- (6) DIODES 1N4002
- (6) CAPACITORS, CERAMIC DISC .001 uf
- (6) SO239 CHASSIS MOUNT CONNECTORS